

## EPLGS-0.6 Guidance Lines FOR NON-CARPETED STEPS AND CORRIDORS Installation Instructions

### Preparation of Surface:

- 1 Ensure surface is clean of dirt, dust and debris.
- 2 If sealant has been applied to the concrete steps, we recommend contacting Clarion to check compatibility.

### Alignment:

- 3 Place one piece of strip on the top step and one on the bottom step.
- 4 Run a string line from the left edge of the top to the left edge of bottom. This will give you a straight, true line.

**Note:** The maximum recommended length for installation in outdoor situations is 5', with a minimum 1/5" gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.

- 5 Lay the strip upside down and clean off any possible residue from the underside.
- 6 Using a cartridge glue gun, apply a 1/8" bead of the recommended polyurethane adhesive along the full length of the underside of strip.
- 7 Turn the strip back to right side up and press onto step.
- 8 Apply downward pressure to ensure a good bond along its full length. If any adhesive squeezes out around the edges, wait until it cures before removing by trimming off with a box-cutter-type cutting blade.
- 9 Immediately following installation, close off the area for a period of 8 hours to avoid movement while the adhesive is in the early stages of "cure".

